

Operation and Service Manual for HERMetric PRESS all versions



Note: before using the instrument
please read this book.



This document is subject to changes without notice.
Check updates on www.tanksystem.com or contact us at tanksystem@honeywell.com

1. Table of contents

<u>1.</u>	<u>TABLE OF CONTENTS</u>	<u>2</u>
<u>2.</u>	<u>GENERAL</u>	<u>3</u>
<u>3.</u>	<u>RECOMMENDATION FOR SAFE USE</u>	<u>3</u>
<u>4.</u>	<u>GENERAL INFORMATION</u>	<u>4</u>
4.1	DISCLAIMER	4
4.2	SHIPMENT NOTE	4
4.3	INITIAL INSPECTION	4
4.4	DOCUMENTATION DISCREPANCIES	4
4.5	WARRANTY	4
4.6	SPARE PARTS	5
4.7	SERVICE AND REPAIR	5
<u>5.</u>	<u>WORLDWIDE SERVICE STATIONS NETWORK</u>	<u>7</u>
<u>6.</u>	<u>OPERATION</u>	<u>9</u>
<u>7.</u>	<u>MAINTENANCE</u>	<u>9</u>
7.1	CARE	9
<u>8.</u>	<u>DRAWINGS</u>	<u>9</u>

2. General

The HERMetic Press is designed for verification of pressure/vacuum in closed and inerted tanks.

It has to be used on HERMetic Compact/Deck Valves.

With the HERMetic PRESS connected to the valve connector nipple, the assembly is gas tight.

3. Recommendation for safe use

This Operation and Service Manual is a guide in order to help the user to operate the instrument safely and correctly.

Nevertheless the maker disclaims all responsibility and liability for damage resulting from the use of the equipment regardless of the cause of the damage.

This product and his use is / may be related to international, national, local or company regulations or standards. It is the customer / user responsibility to ensure that the way to use the device complies with such applicable regulations or standards.

This device is a portable product. It must not be permanently installed on the tank and must be disconnected after use and stored in a safe and dry area.

4. General information

4.1 Disclaimer

This manual is designed and written to provide information with regard to the subject matter involved. Enraf Tanksystem SA makes no warranty, express or implied, that it is fit for any purpose whatsoever; or to the absolute sufficiency of the material presented.

Enraf Tanksystem SA assumes no responsibility for any inaccuracies in reproduction or errors in interpretation of any authority. Enraf Tanksystem SA reserves the right to modify or amend this manual, without prior notification, but Enraf Tanksystem SA assumes no responsibility to update or issue corrections.

4.2 Shipment note

The following parts should be included in the shipment:

- 1 instrument;
- 1 Operation and Service Manual.

4.3 Initial inspection

Check the contents of the shipment for completeness and note whether any damage has occurred during transport. Carry out the "Initial test before installing the instrument" to verify the good functioning. If the contents are incomplete, or if there is damage, do not use the device. A claim should be filled with the carrier immediately, and Enraf Tanksystem SA Sales or Service organization should be notified in order to facilitate the repair or replacement of the instrument.

4.4 Documentation discrepancies

The design of the instrument is subject to continuous development and improvement. Consequently, the instrument may incorporate minor changes in detail from the information contained in the manual.

4.5 Warranty

12 months after installation but max. 18 months after delivery ex works.

The Vendor undertakes to remedy any defect resulting from faulty design materials or workmanship. The Vendor's obligation is limited to the repair or replacement of such defective parts by his own plant or one of his authorized service stations. The Purchaser shall bear the cost and risk of transportation of defective parts and repaired parts supplied in replacement of such defective parts.

This warranty does not apply to those items which by their nature are subject to deterioration or consumption in normal service, and which must be cleaned, or replaced on a routine basis.

When returned to Enraf Tanksystem SA equipment must be contamination-free. If it is determined that the Purchaser's equipment is contaminated, it will be returned to the Purchaser at the Purchaser's expense. Contaminated equipment will not be repaired, replaced, or covered under any warranty until such time that the Purchaser decontaminates the said equipment.

The Purchaser shall notify by fax, telex or in writing of any defect immediately upon discovery, specifying the nature of the defect and/or the extent of the damage caused thereby.

Where no other conditions have been negotiated between the Vendor and the Purchaser "General Conditions 188" of United Nations shall apply.

Unauthorized repair or component replacement by non original spare parts by the Purchaser will void this guarantee and may impair the good functioning of the instrument.

This warranty is expressly in lieu of any and all other warranties and representations expressed or implied, and all other obligations or liabilities on the part of the Vendor (Enraf Tanksystem SA) including but not limited to, the warranty of merchantability or fitness for a particular purpose.

In no event shall Enraf Tanksystem SA be liable for indirect, incidental or consequential loss or

damage or failure of any kind connected with the use of its products or failure of its products to function or operate properly.

Enraf Tanksystem SA do not assume the indemnification for any accident or damage caused by the operation of its product and the warranty is limited to the replacement of parts or complete goods.

4.6 Spare parts

When ordering spares identify the spare part by TS number and description. Refer to section "Drawings".

Some spares might be repairable; in this case send part to any authorized service center or to the factory.

In case of urgency replacement units can be available while stocks last.

4.7 Service and Repair

The customer should take care of the freight and customs clearance charges. If units are sent on "freight collect " the charges will be invoiced to the customer.

When returning units or parts for repair to the factory please fill out a service request form (see next page).

Service Request

Customer's address:

Telephone:

Telex:

Fax:

Type of unit or part:

Short description of defective unit or part:

Do you want a quotation before repair is started:.....yes / no.....

Repaired unit has to be returned to the following address:

.....

5. Worldwide Service Stations network

The updated list can be found on our website www.tanksystem.com

COUNTRY	ADDRESS	TELEPHONE/FAX/E-MAIL
SWITZERLAND	ENRAF TANKSYSTEM SA 2, rue de l'Industrie CH-1630 BULLE	Tel : +41-26-91 91 500 Fax : +41-26-91 91 505 Tanksystem@honeywell.com
CANADA	PYLON ATLANTIC A Div. Of Pylon Electronics Inc. 31 Trider Crescent., DARTMOUTH, N.S. B3B 1V6	Tel : +1-902-4683344 Fax : +1-902-4681203 halifax_csr@pylonelectronics.com
CHINA	HUA HAI EQUIPMENT & ENGINEERING CO LTD Factory 7, Lane 1365, East Kang Qiao Road Kang Qiao Industrial Zone, Pu Dong SHANGHAI, P.C. 201315	Tel : +86-21-68183183 Fax : +86-21-68183115 huahaish@huahaiee.com
GREECE	SPANMARIN 86, Filonos Street GR-185 36 PIRAEUS	Tel : +30-210-4294498 Fax : +30-210-4294495 spanmarin@ath.forthnet.gr
JAPAN	DAIWA HANBAI CORPORATION LTD 2-10-31, Mitejima, Nishiyodogawa-ku OSAKA 555-0012	Tel : +81-6-64714701 Fax : +81-6-64729008 daiwa471@silver.ocn.ne.jp
KOREA	World Ocean CO., LTD Rm1001, Hae-deok Bldg., 1212-11 Choryang-dong Dong-Gu BUSAN	Tel : +82-51-462-2554/5 Fax : +82-51-462-0468 marine@worldocean.co.kr
MEXICO	URBAN DEL GOLFO S.A. DE C.V. Ave. Ejército Mexicano 1902 Col. Loma del Gallo 89460 CD. MADERO, TAMPS. MEXICO	Tel : +52-833-2170190 Fax : +52-833-2170190 urbansa@prodigy.net.mx
NETHERLANDS	B.V. TECHNISCH BUREAU UITTENBOGAART Brugwachter 13 NL-3034 KD ROTTERDAM	Tel : +31-10-4114614 Fax : +31-10-4141004 info@tbu.nl

The updated list can be found on our website www.tanksystem.com

COUNTRY	ADDRESS	TELEPHONE/FAX/E-MAIL
PORTUGAL	CONTROLIS Soc. Com. Equipamentos de Controlo, Lda. Rua Conceição Sameiro Antunes, 26E 2800-379 COVA DA PIEDADE	Tel : +351-21-2740606 Fax : +351-21-2740897 controlis@netc.pt
RUSSIA	NPP "GERDA" Vilisa Latsisa str. 17 Building 1 125480 MOSCOW	Tel : +7-495-7558845 Fax : +7-495-7558846 info@gerda.ru
SINGAPORE	HUBBELL INT'L (1976) PTE LTD 322 Thomson Road SINGAPORE 307665	Tel : +65-6-2557281 Tel : +65-6-2550464 Fax : +65-6-2532098 hubbell@mbox2.singnet.com.sg
SPAIN	E.N.I. Electronica y Neumatica Industrial, S.A. C/Jon Arrospide, 20 (Int.) 48014 BILBAO	Tel : +34-94-4746263 Fax : +34-94-4745868 eni.tecnica@eni.es
SWEDEN	INSTRUMENTKONTROLL Lars Petersson AB Varholmsgatan 1 414 74 GÖTEBORG	Tel : +46-31-240510 Tel : +46-31-240525 Fax : +46-31-243710 Info@instrumentkontroll.se
TURKEY	YEDI DENIZ Setustu, Izzetpasa Yok.1 TR 34427 Kabatas ISTANBUL	Tel : +90.212.251 64 10 / 3 lines Fax : +90.212.251 05 75 servicestation@yedideniz.net
UNITED ARAB EMIRATES	MARITRONICS TRADING L.L.C. P.O. Box 6488 Shed # 72, Jadaf Ship Docking Yard DUBAI	Tel : +971-4-3247500 Fax : +971-4-3242500 service@maritronics.com
UNITED KINGDOM	ENERGY MARINE (INTERNATIONAL) LTD. 12 Clipstone Brook Industrial Estate Cherrycourt Way LEIGHTON BUZZARD, BEDS LU7 4TX	Tel : +44-1525-851234 Fax : +44-1525-852345 info@engmar.com
U.S.A / TEXAS	HONEYWELL HERMETIC 4522 Center Street DEER PARK, TX 77536	Tel : +1-281-930 1777 Fax : +1-281-930 1222 Toll free call in the USA: 1-800-900 1778 hermetic@honeywell.com

6. Operation

1. install the HERMetric PRESS on the HERMetric valve via the quick coupling device.
2. Open the valve. The HERMetric PRESS is then in direct contact with the tank atmosphere, and pressure or vacuum is indicated on the manometer, which is graduated from - 1500 to + 2500 MM water column.
3. Read the pressure.
4. Close the valve.
5. Disconnect the HERMetric PRESS.
6. Clean the HERMetric PRESS before the next check.

7. Maintenance

7.1 Care



For long service life, keep the HERMetric Press clean and well lubricated and, when not in use, store it in a dry and protected location.

To adjust the zero of the manometer, remove the rubber blanket and the top cover. Turn the adjusting screw located in the centre of the manometer.

When ordering spare parts, always state the drawing and the item number.

8. Drawings

	ND	TS	DESCRIPTION
	30275	10069	Press stainless steel 1" mmWC
	30415	10020	Press stainless steel 1" mmWC
	41039	22564	Adaptor 1 1/2"





Item	Ql	Weight	Description	Material	TS #	ND #
1	1	157	Protection gauge	NBR	17502	-
2	1	524	Gauge 61/2" graduated mmWC	1.44.35	17503	40801
3	1	494	Storage tube 1" Oxy. Press, Dip 1	AISI 304	16010	30595
4	1	4	O-Ring 429.75x3.53	FFKM	1114.7	-
5	1	5	Label "Tanksystem"	-	50006	40343
6	1	1	Label "Press"	-	50008	40346

TOLERANCES UNLESS OTHERWISE SPECIFIED				Weight:	1185 Th.	
Norm. Size	Over	To	Angles	1185	0 Eff.	
Fit	6	30	100	300	1000	2000
Fine	±	0.05	0.1	0.15	0.2	0.3
REMOVE ALL BURRS AND SHARP EDGES				0.1*		

Drawn:	CPI 08.06.1994		Control:					
1:2				MPSA	4110			
				Replaced by:	ND			
				Replacement for:	ND			
				TS	10069			
				ND	30275			
				REF NO				

HERMETIC Press				Press stainless steel 1" mmWC		
Enraf Tanksystem SA				RUE DE L'INDUSTRIE 2 CH-1630 BULLE		
This drawing is our property and must not without our permission be copied or made available to others.				Tel. +41 26 91 500 - Fax +41 26 91 505		
The receiver is responsible for every misuse.						


ISSUE 2 : 14.8.1998



Item	Ql	Weight	Description	Material	TS #	ND #
1	1	157	Protection gauge	NBR	17502	-
2	1	545	Gauge 61/2" graduated mmWC	Brass	17501	40800
3	1	494	Storage tube 1" Oxy. Press, Dip 1	AISI 304	16010	30595
4	1	2	O-Ring 29.7x3.5	FKM	11132	-
5	1	5	Label "Tanksystem"	-	50006	40343
6	1	1	Label "Press"	-	50008	40346

TOLERANCES UNLESS OTHERWISE SPECIFIED			Weight:
Norm. Size	Over	6 30 100 300 1000	1204 Th.
Fit	To	6 30 100 300 1000 2000	0 Eff.
Fine	±	0.05 0.1 0.15 0.2 0.3 0.5 0.1"	

REMOVE ALL BURRS AND SHARP EDGES		1:2
Control:		
Drawn: CPI 08.06.1994		MPSA 4110
Modification		
HERMETIC Press		Replaced by: ND A-408.0.00 ND
Press 1" mmWC		
TS 10020		REF NO
ND 30415		
Enraf Tanksystem SA		RUE DE L'INDUSTRIE 2 CH-1630 BULLE TEL. +41 26 91 500 - Fax +41 26 91 505
This drawing is our property and must not without our permission be copied or made available to others. The receiver is responsible for every misuse.		



Item	Qt	Weight	Description	Material	TS #	ND #
1	1	400	Connector 1" - 2" FKM	-	22563	41032
2	1	5	S Holder	AISI 304	11902	40537
3	1	4	Cable assy	-	55112	40525

TOLERANCES UNLESS OTHERWISE SPECIFIED							
Norm. Size	Over	6	30	100	300	1000	Angles
Fit	To	6	30	100	300	1000	2000
Fine	±	0,05	0,1	0,15	0,2	0,3	0,5
							0,1°

Weight:
409 Th.
0 Eff.

ISSUE 1 : 14.3.1997


REMOVE ALL BURRS AND SHARP EDGES

Drawn:
UPR 14.03.1997

Control:

1:1

MPSA
4110



Replacement for:
ND

Replaced by:
ND

Valves

Adaptor 1"-2"

TS 22564

ND 41039

REF ND

This drawing is our property and must not without our permission be copied or made available to others.
The receiver is responsible for every misuse.

Enraf Tanksystem SA

RUE DE L'INDUSTRIE 2 CH-1630 BULLE
Tel. +41 26 91 91 500 - Fax +41 26 91 91 505